



USB Update Procedure, EHB 3x4



Extend Holding Bin
EHB 3x4 Series

UNPLUG
ALL COMM
CABLES



DISPLAY WILL GO THROUGH **BLCF** → **BLBF** → **BL04...03...02...01...00** (5-7 minutes from start to finish) → **BL00** → **BN04**

- 1) "6XX" = FIRMWARE VERSION ON PCB,
- 2) LETTER + NUMBER => PROGRAMMING DONE



3) Confirm firmware version on USB sticker "6.XX" – ALL BARS



Repeat for backside bar by pressing only PRINCECASTLE

***IF 1-3 ARE NOT TRUE:**
Contact Prince Castle
Tech Support
1-800-722-7853



NOTE: Complete this section only if part replaced was a circuit board with an Ethernet jack.

Peel and stick the “MAC #” sticker over the one in the front right corner of the top cover. Then call Chef tech. support to sync the unit online (1.800.547.4266).

