

# Prince Castle - Holding Bins

## Equipment Preparation Checklist



**WARNING:** To reduce the risk of injury, always unplug your Cornelius equipment before cleaning and performing preventative maintenance. Do not use metal scrapers, sharp objects or abrasives as damage may result to surfaces. Do not use solvents or other unapproved cleaning agents as they may harm plastic materials. Remember to use all appropriate Personal Protective Equipment (PPE) when cleaning and sanitizing.

Cleaning and Preventative Maintenance	
	Turn the unit off and unplug the power cord from the electrical receptacle. Wait 30 minutes for the unit to cool.
	Put on heat resistant neoprene gloves. Remove pans and covers (and racks, if applicable).
	Wipe all parts and unit with a cloth dampened with lukewarm soap and water.
	Wipe again with a clean, sanitized cloth.
	Allow to air dry.
	Reinstall components.
	DO NOT use a green Scotch bright pad cleaner, ice, water, other cleaning substances, or abrasives on any part of the holding bin.
	DO NOT immerse the unit in water.
	DO NOT spray unit.

These instructions are written and meant for you or your staff to perform. For additional assistance performing this maintenance, please refer to your user manual or contact your local service provider.