



INSTALLATION INSTRUCTION

SAFETY INSTRUCTIONS



WARNING:

Before starting installation, read and understand all safety label and warnings on the machine. Also review and understand all safety instructions in the owners, installation and service manuals.

Failure to comply could result in serious injury, death or damage to the equipment.

QUALIFIED SERVICE PERSONNEL



WARNING:

Only trained and certified electrical, plumbing and refrigeration technicians should service this unit.

All wiring and plumbing must conform to national and local codes. Failure to comply could result in serious injury, death or equipment damage.

SAFETY PRECAUTIONS

This unit has been specifically designed to provide protection against personal injury. To ensure continued protection observe the following:



WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.



CAUTION:

Always be sure to keep area around the unit clean and free of clutter.

Failure to keep this area clean may result in injury or equipment damage.

ADA Kit

WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

1. Remove the merchandiser and the splash panel from the unit.




Figure 1.

2. Remove the two connectors from the old circuit board.



Figure 2.

3. Remove the old board by bending the metal bracket on top of the board upward and pulling the board off of the tape holding it to the panel, as shown.




Figure 3.

4. Clean any leftover tape from the panel.




Figure 4.

5. Remove the backing from the double-sided tape on the back of the new PC board.




Figure 5.

6. Mount the new PC board using the double-sided tape to hold the board to the panel and bend the metal bracket down to hold the board in place.




Figure 6.

7. Reinstall the connectors to the new PC board, as shown.




Figure 7.

8. Insert the new wiring harness into the cable guides and run it down between the insulated tubing of the valves, as shown.




Figure 8.

9. Insert the cable connector into the ribbon cable connector attached to the new splash panel. Note the pins must be visible on both connectors for proper ADA button operation, as shown.




Figure 9.

10. Reinstall the splash panel and the merchandiser.




Figure 10.